



Fitting Instructions

FR950

**FORD TRANSIT and TOURNEO Mar 2000 -
RE-DESIGNED**

Bolt Kit

WA	8	12MM LARGE ROUND WASHERS
C	2	16x50 BOLTS, NUTS & GRIP WASHERS
B	4	12x35 BOLTS, NUTS & GRIP WASHERS
A	6	12x90 BOLTS, NUTS & GRIP WASHERS

Contents

CB	1	CROSSBAR
LA	1	LEFT ANGLE
RA	1	RIGHT ANGLE
SP	1	SPACER PLATE

- 1. REMOVE THE SPARE WHEEL.**
- 2. REMOVE THE ORIGINAL BUMPER MOUNTING BOLTS FROM THE CHASSIS RAILS AND DISCARD.**
- 3. LOOSELY ATTACH ANGLES LA AND RA TO THE CHASSIS RAILS USING BOLTS A AND WASHERS WA. THE OTHER WASHERS WA ARE USED AS SPACERS BETWEEN ANGLES LA AND RA AND CHASSIS RAIL ON FORWARD HOLES.**
- 4. ATTACH CROSSBAR CB TO THE ANGLES LA AND RA USING BOLTS B. (WHEN FITTING TO A VEHICLE WITH STEP USE THE FRONT 2 HOLES).**
- 5. ATTACH TOWBALL USING BOLTS C WITH SPACER PLATE SP.**
- 6. TIGHTEN AND CHECK ALL BOLTS.**